



XCUV 700

Home Installer Guide



XUV 700

VARIANT BUILDUP

Sci-fi Technology

	MX	AX3	AX5	AX7	AXL
Infotainment Screen	8-inch	10.25-inch	10.25-inch	10.25-inch	10.25-inch
Sound System	4-Speaker	6-Speaker	6-Speaker	6-Speaker	Sony 3D - 12 Speaker
Sound Staging	—	Yes	Yes	Yes	NA
DIS Screen / Cluster	7-inch	10.25-inch	10.25-inch	10.25-inch	10.25-inch
Adrenox Connect	—	• (1 year subscription)	• (1 year subscription)	• (2 year subscription)	• (2 year subscription)
Built-in Alexa Integration	—	•	•	•	•
360 Degree Surround View System	—	—	—	—	•
Reverse Camera & Park Assist	—	—	—	•	• (360-Degree)
Rear Parking Sensors	•	•	•	•	•
Blind View Monitoring	—	—	—	—	•
Wireless Android Auto/Apple CarPlay	— (Only wired Android Auto)	•	•	•	•
Wireless Smartphone Charging Provision	—	—	—	—	•
Intelli-control	—	—	—	•	•
Auto Booster Headlamp	—	—	•	•	•
DIS Controls	Switch bank on dash board	Switch bank on dash board	Switch bank on dash board	On Steering Wheel	On Steering Wheel

Spirited Performance

	MX	AX3	AX5	AX7	AXL
mStallion Engine	•	•	•	•	•
mHawk Engine	• (155 PS)	• (185 PS)	• (185 PS)	• (185 PS)	• (185 PS)
6-Speed MT	•	•	•	•	• (Only in Diesel)
6-Speed AT	—	•	•	•	•
Drivemodes	—	—	Only on Diesel	Only on Diesel	Only on Diesel
AWD	—	—	—	(Only in Diesel AT)	• (Only in Diesel AT)

World Class Safety


	MX	AX3	AX5	AX7	AXL
Adaptive Cruise Control	—	—	—	• (Only in AT)	• (With stop & go function in AT)
Forward Collision Detection & Autonomous Emergency Braking	—	—	—	•	•
Lane Departure Warning & Lane Keep Assist	—	—	—	•	•
Smart Pilot	—	—	—	• (Only in AT)	• (Only in AT)
High Beam Assist	—	—	—	•	•
Traffic Sign Recognition	—	—	—	•	•
Cruise Control	—	—	—	• (In MT)	• (In MT)
Driver Drowsiness Detection	—	—	—	•	•
Airbags	2	2	4	6	7
Latest generation ESP	—	—	• (Not available in Petrol MT)	•	•
Electronic Park Brake	—	—	—	—	•
ISOFIX	•	•	•	•	•
Personalized Safety Alerts	—	•	•	•	•
Cornering Lamps	—	—	•	•	•

Tough Yet Sophisticated

	MX	AX3	AX5	AX7	AXL
Best in Segment Ride & Handling	—	—	—	• (Only in AT)	• (With stop & go function in AT)
Frequency Selective Damping	—	—	—	•	•
Smart Clean Zone	—	—	—	•	•
6-way power adjustable driver seat with memory	—	—	—	• (Only in AT)	• (Only in AT)
Welcome Retract	—	—	—	•	•
Ergo Lever	—	—	—	•	•
Dual Zone FATC	—	—	—	• (In MT)	• (In MT)
Push Button Start	—	—	—	•	•
Passive Keyless Entry	2	2	4	6	7
Valet Mode	—	—	• (Not available in Petrol MT)	•	•
Auto Headlamps & Wipers	—	—	—	—	•
Rear Wiper & defogger	•	•	•	•	•
Selective Unlock	—	•	•	•	•
MicroHybrid (Manual only)	•	•	•	•	•
Height Adjustable Driver seat	•	•	•	•	•
60:40 Split rear seat (2nd Row)		7 Seater	7 Seater	7 Seater	7 Seater
Rear foldable 100% seat (2nd Row) Fixed Seat	5 Seater	5 Seater	5 Seater		
Front Sliding Armrest	—	—	—	•	•
Rear arm rest and cupholders	NA	7 Seater	7 Seater	7 Seater	7 Seater

Unmissable Presence

	MX	AX3	AX5	AX7	AXL
Clearview LED Headlamps	— (Halogen)	— (Halogen)	•	•	•
Smart Door Handles	Manual	Manual	Manual	Manual	Electric
Diamond Cut Alloy Wheels	—	—	• (17-inch)	• (18-inch)	• (18-inch)
Arrowhead LED tail lamps	•	•	•	•	•
Skyroof	—	—	•	•	•
Sequential LED turn indicators	—	—	•	•	•
Leatherette Seats	—	—	—	•	•
Rear Spoiler	•	•	•	•	•
Front Fog Lamps	—	•	•	•	•
Roof Rails	•	•	•	•	•
Follow-me-Home Headlamps	•	•	•	•	•



XUV 700

Feature Operation

Remote Keyless Entry (RKE) Key Fob

Keys on the Key Fob

- A - LED Indicator
- B - Lock
- C - Boot Unlock/Search
- D - Unlock Button
- E - Mechanical Key Release Button



- Press Lock button to lock XUV700
- Long press to close driver window/skyroof™



- Press unlock button to unlock XUV700
- Long press to open driver window/skyroof™



- Press Boot unlock button to unlock the Boot
- Press it twice within two seconds to locate the vehicle in a parking lot



- Press this button to flip out the mechanical key

MX

AX3


AX5

AX7

AX7L

Door Handles

Smart Door Handles (Electrically Operated)



W62E03

1. The door handles will pop out as shown in the figure if,

If you have the key in your pocket, press the three dots on the handle

OR

Unlock the vehicle using the unlock button on the keyfob



W62E04

2. Pull out the handle to open the door

Manually Operated Door Handles



1. Press unlock button on the key fob



W62E02

2. Push the door handle inwards as shown to pop out the handle



W62E04

3. Pull out the handle to open the door





W62E02

4. The handle will retract automatically after the door is opened

Seat Adjustments – Electrically Operated

AX7 AX7L




Seat Recline

Seat Adjustments – Manual

MX AX3 AX5



Seat Slide



Seat Recline



Seat Height Adjust



Lumbar Adjustment

AX7

AX7L

Memory Seat Position Saving



- Adjust the seat position using the powered seat adjustment controls
- Press the button M
- Press 1, 2, or 3 button within the next 3 seconds
- You will hear a chime, indicating that the position is saved

AX7


AX7L

Recalling Memory Seat Position




- Close the Door
- If the ignition is OFF - Press either 1, 2 or 3 to recall the position saved in it. The seat will move to the saved position
- If the ignition is ON - Long Press either 1, 2 or 3 until the seat moves to the saved position
- You will hear a chime, indicating that the position is restored


ORVM Adjustment




- The ORVM Adjustment lever is located on the driver door pad
- The joystick can be turned to select left or right mirror
- The joystick can be moved to any side to adjust the mirror accordingly



Door Locks, Power windows



A - Fold/Unfold mirrors



Keep the switch in central position to enable

- Auto fold while locking
- Auto unfold at ignition

Steering Rake & Reach adjustment



MX

AX3


AX5

AX7


AX7
L



Tilt Adjustment



Telescopic Adjustment



1. Pull the lever under the steering wheel to **unlock the steering wheel**
2. Raise or lower the steering wheel to the desired position (**Tilt Adjustment**)
3. Pull/Push the steering wheel outwards/inwards to the desired position (**Telescopic Adjustment**)
4. Push the lever back into position to lock the steering wheel

Steering Controls - Audio

MX

AX3

AX5

AX7

AX7L



A - Mute the audio/Pause the song

B - Increase Volume

C - Decrease Volume

D - Pick up call

E - Change Audio Source (Radio/BT, USB etc)

F/G - Change track/Change radio channel

H - Trigger Alexa/End Call

MX

AX3

AX5

AX7

AX7L



Wiper Stalk




Control the wiper function by flicking the wiper stalk into the shown positions

MIST - Flick to this position to activate the wiper once

OFF - Turns off the wiper

AUTO - Turns on Auto wiper (only in AX7 & AX7L)

LOW, HIGH - Perform wipe operation in different speeds



Other controls on the wiper stalk include


AUTO WASH - Press this button to spray washer fluid on to the windshield for 2 seconds & wipers wipe 4 times.

Again, the washer fluid is sprayed for 1.5 seconds and wipers function for 3 times

Push the lever backwards - To activate the rear wash & wipe

Pull the lever forward - To activate the front wash & wipe

Wiper Stalk



Other controls on the wiper stalk include **REAR WIPER ROTARY SWITCH** – All functions of the rear wiper is controlled by this switch. Move the switch to the following positions.

OFF – Rear Wiper OFF

INT- Intermittent Mode, the wiper operates on preset intervals of 4 seconds.

ON - Rear Wiper ON – Operate the wiper continuously



Other controls on the wiper stalk include **WIPER SPEED INTENSITY ROTARY SWITCH**-

The intensity of Auto Wiper can be adjusted using this knob

MX

AX3

AX5

AX7

AX7L



Headlamp Stalk

Control the headlights and fog lights from this stalk



Controls in the right

A - Headlamp Low Beam ON - Turn on headlights in low beam

B - DRL Only

C - AUTO - Headlamps turn ON based on night/day (only in AX7 & AX7L)

D - OFF - Turns OFF Headlamps



Control the fog lights from the inner rotary switch

A - Rear Fog Lamp ON (all variants except MX)

B - Front Fog Lamp ON (all variants except MX)

C - All Fog Lamps OFF

Headlamp Stalk



Other Controls

Move upwards - Turn Left Indicator ON

Move downwards - Turn Right Indicator ON

Move Backwards/Forwards - Toggle between low beam/High Beam

Pull Forwards - Flash the headlamp high beam

AX5

AX7

AX7L

Auto Booster Headlamps



Auto Booster Headlamps turn on when

- Headlamps are in AUTO Mode



- High Beam is activated



- Vehicle speed crosses 80 km/hr

Driver Side Switch Bank

MX AX3 AX5



A - Dummy

B - Turn ESP OFF (Only in AX5 (except petrol manual), AX7 & AX7L)

C & F - Up & Down controls for the DIS screen

D - Menu button for DIS

E - Enter button for DIS

G - Hill Descent Control ON/OFF

H - Electric Start Stop ON/OFF

AX7 AX7L



A - Dummy

B - Turn ESP OFF (Only in AX5 (except petrol manual), AX7 & AX7L)

E - **AWD Lock** (Only in AX7 & AX7L AWD variants)

G - Hill Descent Control ON/OFF

H - Electric Start Stop ON/OFF


AX3

AX5

AX7

AX7L

10.25-inch Infotainment screen




8.0-inch Infotainment screen

MX



Quick Access & App Drawer



App Drawer

Access all inbuilt applications


Quick Access Drawer

Access all important settings quickly

FUN-IN XUV700



Wireless Android Auto/Apple CarPlay



Navigation, 3D Maps and Live Traffic Updates



AdrenoX Connect



Immersive 3D Sound Technology By Sony



Built-in Alexa Integration

FUN-WITH XUV700

AX5

AX7

AX7L


Only in Diesel

In Zap & Zoom Drive Mode

Select the Drive Mode from here




In Zip Drive Mode



Infotainment - Settings

The settings in the infotainment system allows the user to control several features as shown



Sony 3D Sound System

Sony 3D system can be accessed through settings or the equalizer icon (|||) in the music screen



Infotainment – Alexa Setup




Customer can login to the infotainment system's Alexa capability using the following process



This is a comprehensive guide for

- Amazon Alexa setup
- Amazon Alexa Demonstration


Amazon Alexa Setup

1. Download Alexa App from the Play Store/App Store
2. Login to the application using your Amazon account OR Create a new account using your mobile number 
3. Plug in your Echo device to a power outlet
4. Go to Devices section in your Alexa and follow the on screen instructions to add your Echo device and give it a name (Bedroom, Kitchen etc)  
5. Login into the same Amazon account on the XUV700 infotainment screen
6. Your Alexa devices & XUV700 is connected to your Amazon account


Amazon Alexa Demo

1. Offline Commands - Be seated inside the car and try to control the vehicle features

Examples of Offline Commands
Open Windows
Increase blower speed
Increase volume etc

2. Online Commands - Give online commands to the infotainment system, Alexa device, your smartphone. 

Examples of Online Commands
What are the latest sports updates?
What is the temperature in Pune?
Play me some Punjabi songs
Who is Albert Einstein?

3. Home Integration: Ask the Alexa in the infotainment system to control the connected Alexa device. For eg; if your Alexa device is named Bedroom 

Examples of Home Integration Commands
Ask XUV700 "Alexa, Play music in the bedroom"
Ask XUV700 "Alexa, Stop music in the bedroom"

Customer can have any smart device (Smart AC, Smart Lights etc) in their home and control them from XUV700 in the same manner



Alexa Commands

All commands to start with “Alexa”

Sl.No	Commands	Description
1	Increase Volume	Increase volume by one step
2	Increase Volume by X	Increase volume by X step
3	Set Maximum Volume	Set to maximum volume
4	Decrease Volume	Decrease volume by one step
5	Decrease Volume by X bars	Decrease volume by X
6	Mute	Mute the volume
7	Unmute	Unmute the volume
8	Increase Brightness	Increase Brightness by one step
9	Decrease Brightness	Decrease Brightness by one step
10	Maximum Brightness	Maximum Brightness to be set to
11	Minimum Brightness	Minimum Brightness to be set to
12	Optimal Brightness	Set brightness to optimal value
13	BT Audio	Change Source to BT Audio, if source is available
14	FM	Change Source to FM
15	AM	Change Source to AM
16	USB	Change Source to USB , if source available
17	Play Media - to resume playing last	Play Native Media Source
18	Pause Media	Pause Native Media Source
19	Next Song	Next song from native media source
20	Previous Song	Previous song from Native media source
21	Shuffle Song - Enable	Shuffle Songs in the Native media source list
22	Repeat Songs	Repeat a particular song/ list of songs in Native media source
23	Tune to FM/AM Station / Favourite	Tune in to the specific Radio Station (Native)
24	Call from Contacts (Native BT Call)	Call the contact that is displayed as part of contact search in the paired BT Phone
25	Call New Number (Native BT Call)	Call a new number in the BT phone that is currently paired with
26	See New Messages	See e new messages in the BT phone that is currently paired with
27	Reply back to new message	Reply to a new message in the BT phone that is currently paired with
28	Readout the New Text messages	Read out a new text message in the BT phone that is currently paired with
29	Send new message to a contact/Number	Send a text message to a contact in the BT phone that is cursively paired with
30	Search for location	Search for a location or a POI
31	Search for POI - Restuarants	Search for POI in the circle around user
32	Search for POI - Fuel Stations	Search for POI in the circle around user
33	Search for POI - ATM	Search for POI in the circle around user
34	Search for POI - Rest Area	Search for POI in the circle around user
35	Search for POI - Hospital	Search for POI in the circle around user
36	Navigate to the location	Search for a location and start navigation
37	Navigate to the Favourites (Home, Office , Others)	Start Navigation to favorites location
38	Exit navigation/Route	Exit Navigation Exit turn by turn navigation
39	Open Sunroof	Open Sunroof
40	Close Sunroof	Close the sunroof



Alexa Commands

All commands to start with “Alexa”

Sl.No	Commands	Description
41	Open All Windows	Open the windows
42	Close All Windows	Close the windows
43	Ambient Light On	Turn on Ambient Light
44	Ambient Light Off	Turn off Ambient light
45	AC ON	Turn On AC
46	AC OFF	Turn Off AC
47	Fan Off (Full HVAC Off)	Turn Complete HVAC Off
48	Reduce Fan Speed	Reduce Fan speed by one step
49	Increase Fan Speed	Increase fan speed by one step
50	Maximum Fan Speed	Set Fan speed to maximum
51	Minimum Fan Speed	Set Fan speed to minimum
52	Switch to Auto AC mode	Switch to Auto mode from manual mode
53	Increase Temperature	
54	Decrease Temperature	
55	Increase Temperature by x degrees	
56	Decrease Temperature by X Degrees	
57	Set Temperature to specific value	
58	Re-Circulate Air (Inside Car/Outside car)	
59	General Information Enquiry	User can ask alexa any generic queries
60	Weather updates	
61	Online content streaming	Streaming online content on user request (Music /FM /podcast/Audible etc)

Driver Information System

AX7

AX7L


Controlling Driver Information System

These buttons on the steering wheel are used to control the DIS Screen

Menu Button - Used to change the menu

Scroll & Enter - Move up/down to scroll through options, Press to Enter

Favourite Button - Long press while at any screen to set as favourite. Single press to open that screen



MX

AX3

AX5

Controlling Driver Information System



Using the driver side switch bank

C - Up/Down to scroll through options

D - Change Menus

E - Press to enter a menu

Driver Information System – Screens




AC Controls

AX7

AX7L

Dual Zone FATC



- A - Control co-driver side temperature
- B - Front Defogger
- C - Rear Defogger
- D - Increase/Decrease Fan Speed
- E - Turn on Auto AC
- F - Turn on/off recirculation mode
- G - Control Driver side temperature

- H - Turn AC ON
- I - OFF Switch
- J - Turn Rear A/C ON/OFF
- K - Turn on Max A/C for quick cooling
- L - Change A/C Mode
- M - Turn ON/OFF Dual zone FATC (Turning it off will set driver temperature for whole car)


AC Controls

MX

AX3

AX5

Manual AC with Electronic Controls (In lower variants)



- B - Front Defogger
- C - Rear Defogger
- D - Increase/Decrease Fan Speed
- F - Turn on/off recirculation mode
- G - Control temperature

- H - Turn AC ON
- J - Turn Rear A/C ON/OFF
- M - Turn on AC Economy Mode
- N - Select Mode

AC Controls in Infotainment System

The FATC can be controlled via the infotainment system as well


Open App Drawer ► Climate Controls

You can control all functions of FATC from here



Rear AC Controls

2nd Row Vents



The 2nd row vents can be controlled by using the physical controls on the vents

3rd Row Vents

(only in 7 seater models)



The 3rd row vents can be controlled by using the physical controls on the vents

You can also adjust the blower speed by the dial

Other buttons on center console

In all variants, the first three (A, B, & C) are not

buttons. They are indicative lights

A - Light indicating that passenger airbag is ON

B - Light indicating that passenger airbag is OFF

C - Light indicating that passenger seatbelt is not worn

D, E, F & G are buttons that control different features


D - Turn ON/OFF Hazard Lamp

E - Go to Home Page/Turn on Rear View

Camera/Turn on 360-degree surround view (depending on the variant)

F - Turn display OFF


G - Change Drive Modes (Only in Diesel)



Wireless Charging

AX7L

- XUV700 offers a wireless charging pad under the center console
- Place your wireless-charging compatible phone/device on the pad to charge. No activation required



AX7

AX7L

Intellicontrol

Intellicontrol has a control knob that offers different options to control the infotainment screen

Rotate - To control the volume/ move from one option to another

Move left/right - Navigate between options

Move Forward/Backward - Navigate between options

Press - Select an option



The other options on the Intellicontrol are


A - Music - Open Music player

B - Favorite - Open favorite screen (You can select favourite screen by long-pressing this button on any desired screen)

C - Open Home Screen/ Go back

D - Open Phone options

E - Intellicontrol knob




Electronic Parking Brake & Auto Hold

AX7L



6-Speed Automatic Transmission



XUV700 comes with a six-speed Automatic Transmission

P - Park

R - Reverse

N - Neutral

D - Drive

M - Manual



Changing Gears

Press the brake, press the shift knob on the front of the lever and move the brake lever


Manual Gear Changes

While in Drive (D) position, move the lever to the left to engage Manual mode

Move the lever upwards to upshift

Move the lever downwards to downshift

6-Speed Manual Transmission



XUV700 comes with a six-speed Manual Transmission

Engaging Reverse

Lift the reverse gear lock ring (under the gear knob) and shift into reverse

AX7

AX7L

ADAS Features

- Adaptive Cruise Control
- Forward Collision Warning
- Autonomous Emergency Braking
- Lane Departure Warning
- Lane Keep Assist
- High Beam Assist
- Traffic Sign Recognition

AX7


AX7L

Turning ADAS systems ON/OFF in DIS



All ADAS Systems except Adaptive Cruise Control can be turned ON/OFF through DIS


Turning Adaptive Cruise Control ON/OFF



Adaptive Cruise Control can be turned ON/OFF & controlled using these buttons on the steering wheel

- A. Press this button to turn Adaptive Cruise Control ON/OFF

Setting ACC




- B. Move toggle button C to this position to SET cruise control

After Cruise Control is active, move the toggle button again to position B to increase the set speed

Move button C to position B once to increase speed by 1 km/h (eg: 60,61,62....etc)

Long press button C to position B to increase speed by 10 km/h (eg: 60,70,80....etc)




- C. Move toggle button D to this position to reduce SET cruise speed

Move button C to position D once to reduce speed by one kmph (eg: 60, 59, 58....etc)

Long press button C to position D to reduce speed by 10 kmph (eg: 60,50,40....etc)


Setting ACC



- C. Press this button to change the distance maintained from target vehicle

The levels can be toggled between Level 4 ► Level 3 ► Level 2 ► Level 1 ► Level 4

Resuming ACC



- E. Press this button to resume ACC at the previously set speed if
- The driver has braked, and ACC went to standby mode
 - If the target vehicle has stopped for more than 3 seconds and our vehicle has automatically braked.

Parameters of ACC on DIS

Target Vehicle




The vehicle that is followed by XUV700 is shown as the target vehicle

Distance Level



The distance level set from the target vehicle is shown. The levels can be toggled between Level 4 ▶ Level 3 ▶ Level 2 ▶ Level 1 ▶ Level 4

Set Speed



The speed set by the driver for the Cruise Control is shown

ACC Indicator



Shows status of ACC
White - ACC on Standby
Green - ACC Active



Parameters of other ADAS Features on DIS







When the lanes are detected, these lines turn green

The green steering emblem comes on when the steering is assisted by the Lane Keep Assist or Smart Pilot

The Traffic sign recognition shows the speed limit and no overtaking sign here

ADAS Limitation Scenarios



ADAS may not work in the following scenarios



Driver must be always attentive even while using ADAS systems



- The Skyroof™ button on the overhead switchbank has several positions



Functions of each position

Switch Position	Switch Press	Operation
1	Short Press	Sunshade Express Open
	Long Press	Sunshade Manual Open
2	Short Press	Skyroof Express Open
	Long Press	Skyroof Manual Open
3	Short Press	Skyroof Express Close
	Long Press	Skyroof Manual Close
4	Short Press	Sunshade Express Close
	Long Press	Sunshade Manual Close
0 & 5	—	Switch Home/Neutral Position
6	Short Press	Tilt Up
7	Short Press	Tilt Down

Other Skyroof™ controls

Open Skyroof™ from keyfob



Long press unlock button on key fob to open Sunroof

Close Skyroof™ from keyfob



Long press lock button on key fob to close Sunroof

Using Alexa voice commands




Say "Alexa, Open Skyroof™" while inside the vehicle or "Alexa, Ask Mahindra to open Skyroof™" via your Alexa app or Smart device for remote operation

Using AdrenoX Connect




Use the remote Skyroof opening option in the app

Other overhead buttons



Between the front seats

- A - Left Side Reading Lamp
- B - Door/Auto Mode
- C - SOS Calling
- D - Roof Lamp ON
- E - Right Side Reading lamp



Front/Centre Roof Lamp

- A - Permanently ON
- B - Door/Auto Mode
- C - Permanently OFF

Ergo Mode



- Move the front passenger seat from 2nd row for increasing legroom
- Pull out the ergo lever and push/pull the co-driver seat

Only in 7-Seater

2nd row split seat recline and one-touch tumble

- The 2nd- row seat can be folded down with a single lever
- Move the lever on the side of the seat upwards to fold the seat
- This can be operated from the 3rd row seat as well using the lever on the backrest of 2nd row seat



Video Credits : MILE Team

AX
3

AX
5

AX
7

AX
7L

Only in 7-Seater

3rd Row fold

The 3rd row can be folded in 50:50 ratio by using the levers on the back rest



Video Credits : MILE Team

MX

AX3


AX5

AX7

AX7L

Tail gate opening

- Unlock the XUV700
- Press the button under the logo applique to unlatch the boot
- Pull open the boot



MX

AX3

AX5


AX7

AX7L


Child Lock

Child Locks are offered on the two rear-doors which can be activated by moving the lever on the door to position A as shown


To deactivate, move the same lever to position B




Removing Spare wheel



Lift the rear luggage floor panel



Locate the plug covering the spare wheel securing nut



Remove the plug and loosen the nut to lower the spare wheel




The spare wheel will be lowered


It is a temporary spare wheel (Size: T155 / 90 R18)

After replacing the wheel, the original wheel can be stored at the same location as the spare wheel


Jacking the vehicle



Locate the jacking points at the front and rear



Slot the jack into the jacking points
Make sure that it is securely slotted




Insert the jack handle into the jack.
Use the spanner to expand the jack

Tool Box & Emergency kit

Lift the rear luggage floor panel to reveal the tool kit



Contents of Tool Kit



- | | | | |
|---|--|---|----------------------|
| A | Jack Assembly | E | Screwdriver |
| B | Wheel Spanner | F | Jack Operating Lever |
| C | DEO Spanner 10mm x 12mm | G | Tow Bar |
| D | Diesel Filter water drain Tool (Diesel only) | | |

BS6 Maintenance



DEF Filler Position

SCR Alerts

Alerts Related to SCR		
Error Code	Alert Message in Cluster	Action to Taken
E31	DEF LEVEL LOW ENGINE WILL NOT START IN 2400 KM	Fill DEF within 2400 km
E32/E33	DEF LEVEL LOW, ENGINE WILL NOT START IN 800 KM /...KM	Fill DEF within 800 km
E34	NO RESTART ALLOWED, FILL DEF	Fill DEF immediately
E35	NO START ALLOWED, FILL DEF	Fill DEF immediately
E11	INCORRECT DEF, DETECTED / WRONG DEF, DETECTED	Refill with Correct DEF
E12/E13	INCORRECT DEF, ENGINE WILL NOT START IN 800 KM /...KM / WRONG DEF ENGINE WILL NOT START IN 800 KM /...KM	Refill with Correct DEF
E14	NO RESTART ALLOWED, CHECK DEF	Refill with Correct DEF
E15	NO START ALLOWED, CHECK DEF	Refill with Correct DEF
E21	DEF DOSING MALFUNCTIONING	Contact Mahindra Dealer
E22/E23	DEF DOSING MALFUNCTIONING,ENGINE WILL NOT START IN 800 KM / DEF DOSING MALFUNCTIONING,ENGINE WILL NOT START IN ... KM	Contact Mahindra Dealer
E24	NO RESTART ALLOWED , DOSING MALFUNCTIONING	Contact Mahindra Dealer
E25	NO START ALLOWED , DOSING MALFUNCTIONING	Contact Mahindra Dealer

DPF Alerts

Alerts Related to DPF					
Sl no	Symbol	Warning Lamp Status	Engine Performance	Indicates	Action to be taken
1		ON	Normal	DPF is starting to choke	1. Go to the highway and drive above 60 kms/hr for 20-30 min (or) 2. Perform Park Regeneration (or) 3. Take the vehicle to Mahindra Authorized Dealer
	REGEN	ON			
2		Blinking	Limp home	DPF almost fully choked	Perform Park Regeneration (or) Take the vehicle to Mahindra Authorized Dealer
	REGEN	ON			
3		Blinking	Limp home	DPF fully choked	Take the vehicle to Mahindra Authorized Dealer
		ON			

BS6 INFO IN DIS


DEF LEVEL INDICATION



REGEN PROCESS



REGEN PROCESS IN MX VARIANT



Use the OK button on the switch bank to the right side of the steering wheel

